icon Audio

MP 3se Instruction Manual

Pure Valve Single Ended 5 watt Hi Fi and Headphone Amplifier



designed by David Shaw

A Simple No Compromise High End Pure Valve Amplifier

The MP 3 Story:

For a long time we have wanted to create a simple low cost, high quality all valve amplifier that would serve as either an introduction to the joys of a pure valve amplifier or as a secondary amplifier for those needing lower lever sound in another room. The bedroom or study for example.

Using our experience gained in the production of the ST20SE and HP8SE we decided to use the chassis and overall layout of the HP8

The conventional way to provide a headphone output on an amplifier is to drop the power through a resistor. This has a big problem that it provides very high source impedance (rather like a weak battery) the effect of this is to give very "Low FI" results. Ideally headphones should be driven from small high quality amplifiers. Many headphone amplifiers use small "microchip" amps which although are a better solution still do not provide ideal matching to the wide range of headphones available.

The first stage gain uses the excellent ECC83 for voltage gain. The 2nd half is used as a cathode follower, an excellent way of buffering the ECC83 to the EL84 output valve. This wonderful valve has exceptional detail and fluidity. Its smoothness complements the superb EL84 (small version of the EL34 probably the most popular of output HI FI

valves). This combination will give you a simply stunning insight into inner detail of your favourite recordings whether Analogue or digital.

We have also provided speaker terminals on the rear to further increase the versatility. Although 5+5w (RMS) does sound much it can give surprisingly good results in an office or bedroom environment where high sound levels are not required. Indeed, used with medium to high efficiency speakers.

Like our other amplifiers, close attention has been paid to the finish of the MP 3. It uses the same "Bullet Proof"* build (*Hi Fi News/Hi Fi Choice) as our other amplifiers with a combination of anodised alloy plate, stainless and painted steel. We do not use "tin and plastic"!

For space saving we have used the same "lengthways" chassis as our phono pre-amp so it will fit nicely alongside your existing equipment, with the connections on the rear, and headphone socket at the front

The MP 3 is very versatile. It may used in several ways:

- 1, As a small hi fi amplifier from any normal line input e.g. CD/DAC/Tuner etc using speakers of headphones.
- 2, Connect direct from your phones earphone socket in the deadicated 3.5mm input.
- 3, As a headphone amplifier connect to the output of your hi fi system.

QUICK SET UP GUIDE

- **1 Unpack unit carefully**. Make sure that it is in good condition. It is important that you keep packaging for warranty/service return.
- **2 Fit the valves if necessary.** Or if fitted check that they are seated properly. (see also valve replacement)
- 3 You may connect directly to your source unit (e.g. CD player) or from the "Record Out" of your amplifier. You can also use an MP3 unit or similar by selecting the input from the front.
- 3a You can select between headphones and loudspeakers by using the switch on the rear.
- 4 Connect to mains supply using the attached mains lead to 230/240v supply. If it is necessary to change to a different type of mains plug, the welded plug must be removed and replaced with a suitable type. Please then remove fuse and dispose of carefully. (As they can be a danger to children if plugged in). The replacement plug should be wired in the following way Brown to Live terminal, Blue to Neutral terminal and Green/Yellow to Earth terminal.

6 Connect your headphones and SWITCH ON!

The blue mains indicator should light up and unit will take approximately 40 seconds to start working. All valves should have a visible orange glow from the cathode heaters. With the volume control set to minimum (fully anti-clockwise) there should be no sound coming from your headphones except a barely discernable hum.

6a, Headphone Impedance

The dedicated headphone winding in the output transformer is suitable for headphones from 16 to 600 ohms

- **7 Your unit should now be functioning**. If not check wiring again. Use front selector to choose source program and suitable listening volume. The best sound quality will be when the unit has warmed up for at least 20 mins.
- **8 Health and Safety**. The valves when operating have moderately high surface temperatures. Keep out of reach of children and pets.

Under no circumstances operate with valves removed!

Like all amplifiers there are potentially lethal voltages inside (300v DC), which when switched off can take up to 15 mins to discharge! Do not remove bottom panel unless you are a competent engineer. There are no user serviceable parts inside. Like other household electrical appliances do not leave unattended whilst switched on.

Connecting inputs & outputs

Many problems with hi fi equipment involve connecting leads which are usually either 'Bad, or Wrong connection'. So it's worth making sure that you have good connections and that your leads are the right way round.

Inputs

The amplifier will work with any standard piece of hi fi e.g. CD, Tuner, Tape Deck, Mini Disc, TV, Video Recorder, DVD etc.

General points

- Mobile phone 'breakthrough' is normal
- A switch-off 'click' through the speakers is normal.
- Storage in damp conditions could damage transformers.

Connecting Leads

Use good quality connecting leads, which are no longer than they need to be.

Leaving the amp switched on

People sometimes ask if the amp should be left running 24/7 without switching off. Whilst the amplifier will sound at its best when it is properly warmed up, there is no advantage leaving it switched on when it is not in use. It is using electricity and valves have a finite life. Conversely the valves and other components are stressed more at switch on; therefore do not switch on and off unnecessarily. Although the amplifier should sound good within a few minutes like most hi fi units it will take a couple of months of regular use before it is 'run in'.

Cabinet Care

To remove dust from the cabinet and valves we suggest gentle brushing with a soft paintbrush and a duster. Finger marks can usually be removed with a damp cloth. Always clean with the power disconnected.

CAUTION - HEALTH & SAFETY!

When making any adjustments remember to isolate from power supply, and remember that high voltages can remain present inside for some time after switch off.

Trouble Shooting

Amplifier Dead

Check the 1amp mains fuse which is in the IEC mains socket on the rear. Replacements should be 20mm 1Amp 'anti-surge' or "T" type. These are available from Icon Audio should you have any difficulty.

The fuse in the mains plug should be a 3 or 5 amp fuse, although unlikely, this should be checked if the amplifier fuse is OK.

No sound

Have you selected the right input? Are the connections OK? Is everything switched on? Are the speakers/headphones connected?

Distorted sound.

Try another source; if sound improves then it's probably something wrong with the first source. If no improvement try different speakers, if no improvement could be an amplifier problem.

Hum Problems

These are generally caused by "bad" earths or

A common cause is a 'hum loop' caused by having too many earths, and may be identified by unplugging each input source from the mains. One remedy for this is to use an interconnect which only has the screen connected at one end. Other causes of low-level hum can be from adjacent equipment, so experiment with moving equipment around to see if this makes the hum better or worse.

One channel missing.

Usually 'bad' connection on either the input or the speakers. Try swapping the connection over to establish if the cause is:

- Sound will move to the other (a) Input to the amp. channel.
- (b) Amplifier or speakers. Sound will not move.

Strange noises coming from speakers

Turn volume to minimum on unused input, if problem corrected either fault with source unit or with connection. If noise persists, problem with amplifier.

A valve that is lit up is not a guarantee that it is working properly; conversely a valve that is not lit up will not be working.

Valve Replacement

Valve life will depend upon such things as hours of use and number of on/off cycles. As all the valves are lightly loaded. As a rough guide we would estimate life of approx 2 to 5 years. But this can vary.

What can happen?

A valve is at the end of its life if one of the following happens:

- ECC83's are twin triode valves. One of the two heaters may fail.
- A valve could get "noisy" or "microphonic"
- The emission (and therefore output and sound quality) may fall.
- The valve works intermittently.
- An air leak causes the silver "getter" material to turn white.

It is essential that only the correct valves are used as some similar looking valves have a different pin connection and insertion could result in damage to the amplifier and risk of electric shock. It is not good practice to remove the valves unnecessarily as this can strain the pins and cause tiny air leaks. Icon Audio are happy to replace valves and check to performance of your amplifier, and advise on the latest upgrades available.

Method:

Switch off, disconnect from mains and allow to stand for 20 mins to allow voltages to discharge. Undo the 6x Allan bolts Remove cover. Replace valves as necessary. Replace cover and test. Do not operate without cover!

Service: Should you suspect a problem, you could return the unit to your dealer or Icon Audio for a periodic service or return the valves for testing free of charge. You should carefully remove the valves they should be well packed in cardboard & foam or similar, and returned to Icon Audio. (Valves are very rugged if packed properly).

We welcome any comments you may have regarding errors or omissions in this manual.

Should you need further advice or information regarding the use of this unit please contact us.

NEW OWNER?

If you have bought this unit from someone else, please register with us by email or post stating your name, address, model, serial number and whom you purchased from in order that we can keep you up to date with upgrades and improvements

Specifications and Features

- All hand wired point to point
- No printed circuit board to 'colour' sound
- Japanese Blue ALPS volume pot.
- Class A, all Triode circuit
- Custom, hand wound transformers
- Output impedance matching from 8 to 600Ω phones
- 2 x EL84s
- 2 x ECC83 first stage valve
- 2 x 4.5w continuous per channel max
- Signal to noise level -90db
- Freq response better than 20hz-20kHz
- Total harmonic distortion typically less than 0.2% 1khz
- Suitable for 4 to 12 ohm loudspeakers (8 for max power)
- Japanese steel EI transformers with low oxygen copper
- Slim profile design
- High quality 2W metal film, & wire-wound resistors
- Blue LED mains indicator
- Polypropylene audio capacitors
- Silver coated PTFE audio cable
- Custom hand wound output transformers
- Ceramic valve holders for minimum leakage
- Gold plated Input & speaker terminals
- One line or phone low impedance input.
- 300mv input sensitivity.
- 230-240v (or 117v) 50/60 Hz 50 watts.
- C E, ROHS and WEEE compliant where applicable.
- 11cm W, 35 cm D, 14.8 H, 7 kg (remember to allow space for connections)
 (Specifications subject to change, errors & omissions excepted. General 18/11/20)

icon Audio (UK) Ltd

351 Aylestone Road Leicester LE2 8TA www.iconaudio.com

email: sales@iconaudio.com Ph +44 (0) 116 244 0593 +44 (0) 7787 158791

Final Inspection

This amplifier has been carefully checked, tested and final adjustments made by Icon Audio in Leicester.

It has passed our rigorous listening test and final inspection to assure you of optimum performance and reliability.

| Date | / | | |
|--|-------|------------------------|-------|
| Model | | | |
| Amp Serial Number | | | |
| Customer | | | |
| | | | |
| Check amplifier finish | | IEC Mains Fuse | A |
| Run 6 hour test | | Sales invoice | |
| Check inputs/outputs | | Credit card receipt | |
| Sound Quality | | Chassis linearity | |
| Channel Balance Valve Microphony Valve Seating | | Bias meter | N/A |
| | | Transformer Protection | N/A |
| | | Upgrades: | 14/71 |
| Hum & noise level | | Output valve | |
| RF Test | | Capacitors | |
| Serial No sticker and reco | orded | Interconnects | ••••• |
| Mains voltage 230/240V or 117v (changeable) | | merconnects | |
| | | | |
| Signed off by | | | |
| Notes: | | | |

To get the best out of your unit and to save time please read this information & keep it to hand for reference

Please note we do not test the standard mains lead.